


In-Use Screen

After a Massage program is selected, In-use screen displays all settings to that program.



- 1 Time remaining**
 Displays time remaining in current massage program. Press this button to increase the massage session time in 5-minute increments.
- 2 Active airbags**
- 3 Heat symbol**
 Lumbar Heat
 Press to turn on lumbar heat. Press again to turn off.
- 4 Indicators**
 Scanning
 While this indicator is showing, the chair is scanning your back contour and preparing to begin your massage.
 Ready
 Scanning is complete and chair is ready to begin.
 Pause
 Indicates that the chair is paused. Press the pause button on the remote to resume massage.
- 5 Recline adjustment buttons**
 Will light up when the back or foot is moving, indicating the direction of travel
- 6 Icons**
 Displays which massage technique is currently active.
- 7 Direction of rollers**
- 8 Back-roller position**
 Message Rollers Up/Down
 Press this button up or down during your massage to adjust the position of the massage roller mechanism. The yellow dots indicate the current position of the back-rollers.
- 9 Width/Intensity/Speed Indicators**
 These indicators show the roller width, airbag intensity, and tapping/kneading speed that you currently have. Use the **Width**, **Air Intensity**, or **Speed** buttons on the remote control to toggle the levels of these functions.

Auto Programs

Full Body
 Inspired by Thai massage. The strong kneading and stretching functions effectively decompress the entire body. This program is the best choice to relax tired muscles and increase physical vigor.

Renew
 Relaxes muscles and speeds up recovery time by promoting circulation. Try this program after sports activities and exercise.

Upper Body
 Selected neck & shoulder massage techniques for soothing pain and tension in the neck and shoulders.

Lower Body
 Focuses on the lumbar vertebra with targeted massage to relieve tension in this area. This program is recommended to relieve lower back pain.

Stretch
 Yoga like stretching motions. Helps to boost the vitality of muscles. Designed for morning or midday relaxing.

All Air
 A full-body airbag-only massage. This program is best for when gentle relief is needed.

Sooth
 Performs a strong massage to ease muscles and recuperate the body. This is a great program for people who work at a desk or travel a lot.

Night
 Kneads the entire body with a gradual lightening of intensity massage to relieve tired muscles. Try this program as you prepare your body to rest for the night.


KYOTA | The World's Most Advanced Massage Chairs®

72 Stard Road, Seabrook, NH 03874 | (800) 242-0761
 www.kyotamassagechairs.com

Version 1.0

KYOTA®

Quick Start Guide



E330 Kofuko Massage Chair

KYOTA®

Multi-Functional Screen - Displays chairs functions when in use.

Demo Massage Program - Press for a quick demonstration of all available massage techniques.

Zero Gravity - Press once to place the chair in recline position. Press twice to place the chair in zero gravity position 1. Press three times to place the chair in zero gravity position 2. Press four times to return the chair to the recline position.

Auto Programs - Select from 8 preset auto programs.


Manual Massage - Press to toggle between manual massage techniques. Lights below indicate technique number: #1 = 1 light, #2 = 2 lights, etc.

Foot Up/Down - Press and hold up arrow to raise the footrest, press and hold down arrow to recline the footrest.

Back Up/Down - Press and hold up arrow to raise the backrest, press and hold down arrow to recline the backrest.

Massage Roller Up/Down - Press and hold up arrow to raise the back rollers, press and hold down arrow to recline the back rollers While in body scanning mode or manual target

+5 Minute Timer - Press this button to increase the massage session time in 5-minute increments.



On/Off - Powers up the remote or returns the chair to the exit position and powers down remote.

Lumbar heat - Press to turn on lumbar heat. Press again to turn off.

Pause - Press this button to force stop the chair during a program. This will stop all functions immediately. Press again to resume functions.

Speed - Press this button to adjust the tapping/kneading massage speed. Choose from three speeds.

Back Zone - Press this button to select the massage roller zone. Choose from full coverage, upper back, lower back, or targeted (point) massage.

Width - Press this button to adjust the massage roller width. Choose from three width levels.

Foot Roller - Press this button to turn the foot rollers on or off.

Air Massage Zone - Press this button to select airbag regions. Choose from: foot & calf; arms; shoulders; foot, calf & arms; full (foot, calf, arms, & shoulders); or none.

Air Massage Strength - Press this button to adjust the air massage strength. Choose from three intensity levels.